#### continuation

- As soon as the inserted wax candle has been lit, the door of the lantern must be closed immediately.
- To extinguish wax candles, do not simply blow them out but use a suitable candle extinguisher (candlesnuffer).

#### Care instructions

Warning - danger of burns - when caring for or cleaning the lantern, please always make sure that the lantern has cooled sufficiently after using wax candles or even after long periods of sunlight.

- Depending on the model, the surface of the lantern is made of powder-coated aluminum, granite/slate, stainless steel and chrome-plated materials. Care should therefore only be carried out with suitable and gentle cleaners. This also applies to foiled or carbon lanterns.
- The handle made of genuine leather should be treated regularly with a good and preferably colorless leather care product.
- The glass surfaces are best cleaned with a standard glass cleaner. Please make sure that the glass surfaces have cooled sufficiently after using a wax candle.
- Those who do not like the natural teak patina on the outside of the lantern can oiling the wood - but also only on the outside - regularly.
- When caring for the lantern, do not use benzine or other flammable cleaning agents, as well as scratching sponges or other hard objects.

www.lineamare.de



# Important Note

Safety instructions are subject to regular updates. Link to the currently valid version: www.lineamare.de/ imprint/advice



Instruction manual Safety instructions

Lineamare - Erlenweg 1 - D-76337 Waldbronn - Germany - info@lineamare.de

## Instructions and warning signs for the lantern

Thank you and congratulations for choosing an individual light object from Lineamare.

You have thus acquired a handmade product, which was produced in small handicraft companies from Germany. Each lantern is unique and can therefore differ slightly in its structure, surface, colors and workmanship as well as its

weight and dimensions.

Please read the following instructions carefully before starting the first operation

and observe them in principle whenever you use your lantern.

The lantern should primarily be equipped with LED candles (Important: Please observe the safety instructions of the respective manufacturer) - alternatively with 1-wick wax candles - which are neither part of the product nor included in

## Important safety & warning signs

the scope of delivery.

- Attention Important your safety is important to us When using the lantern, it is recommended to only use LED candles. This is particularly true on yachts or in areas that are not constantly monitored as well as with
- foiled and carbon lanterns.
   Warning danger of suffocation This lantern, as well as its packaging, are not toys and should therefore be kept away from children as well as from
- pets. There may be a choking hazard.
   Warning burn hazard always keep children and pets away from the lantern as long as there is a wax candle burning and the lantern has not been completely cooled down.

- rn
- ▲ Warning burn hazard The top (lids, handles) as well as the outer sides (metal parts, glass surfaces) of the lantern, can become hot during longer burning time of used wax candles or intense solar radiation (sunlight).
  - ▲ Warning fire hazard Never allow the candles to burn down completely.

    Replace the installed wax candles at the latest if their height (measured from the candle bettom to the bettom of the flame) is ctill 5 cm.
  - the candle bottom to the bottom of the flame) is still 5 cm.

     Warning fire hazard Neither with burning candle, nor if the candle is hot:

    No combustible objects, such as decorative items, may be placed at the same time inside the lantern nor may the lantern be fully or partially
  - covered.

     Warning fire hazard Never leave the lantern unattended if it burns a wax candle. Therefore, always extinguish wax candles when you move away from the lantern.

### Notes on positioning/placement

and protect the lanterns adequately.

- Place the lantern only on flat and non-slip floors that are sufficiently stable, secured, normally tempered, dry and fireproof. A placement on other surfaces, as well as on tables, cabinets or other shelves is at your own risk. The feet of the lantern should be abrasion-resistant on such surfaces. However, a check for possible abrasion or traces is generally recommended before installation.
- In the event of storms, thunderstorms, frost or other bad weather conditions, as well as on yachts on the way (boating), ensure or protect the lantern sufficiently - and extinguish any lit wax candles (which is according to our advices above, on your own risk).
- on your own risk).
  Even if the lanterns are extensively protected against rust, it cannot be prevented that environmental influences, salt air or sun can harm the surfaces. Therefore, avoid locations where the lanterns are exposed to these for days

- Move, tilt or wear the lantern only if a wax candle is not lit in it.
- In case of longer absence, we recommend to protect the completely cooled lantern from environmental influences (storms, salt water, sun) and to stow.
- cover or store it in a suitable way.
  Always ensure a sufficient distance from the lantern to other burning or combustible chiects.
- combustible objects.

   When using wax candles or LED candles with real wax, avoid direct sunlight /
- heat, as these can then melt.

   When used indoors, generally pay attention to adequate oxygen supply.

protection, placement, storage or maintenance of the lanterns.

▲ Lineamare accepts no liability for improper installation - or inadequate

## Operating instructions

through the door opening. Depending on the lantern model, open and close the door either by carefully turning the door handle 90 degrees to the left or right - or for models with a granite base, by carefully pulling and pushing the door handle.

• When using wax candles, only one wick may be used per lantern. The candle

· Candles that are not burning or have cooled down are put in or taken out

- must not be thicker than the device provided at the bottom of the lantern and must be placed in the middle.
- The height of any wax candle used, may not be higher than 1/4 the height of the lantern in which the candle is placed.
- For lanterns without a drip tray, a flat, suitable and fireproof bowl can be placed on the floor (below the opening) to hold the candle to prevent wax from escaping.